

This item has been replaced with the OR38



Pkg. of 1

# OR34

# MINI PLANER BOARD, YELLOW

## "The Ultimate Mini Planer"

### HOW TO USE YOUR MINI PLANER BOARD


Our Double Agent! The OR34 works for both sides! You decide whether you run it on the port or starboard side! It is reversible — you change sides by switching the direction of the bracket! One Board...Dual Purpose!



PRO RIGGING

OR

SLIDE DOWN RIGGING



Swivel & Split Ring Detail Assembly

Bracket Detail Assembly

Assembly shown is for running this board off of your port side. Simply reverse the direction of the bracket to run the board off of the starboard side.



Heavy Tension



Light Tension

You can adjust the tension of the release/clip by positioning the spring as shown above.

The pinch pad release/clip system allows you to easily attach and remove this board from your rod line. Simply let out your lure or light bait to your desired distance, place the line in the snap swivel or OR16 clip (depending on which rigging method you prefer) and then into the pads of the OR10 release on the bracket. Continue to then let out your line to the final desired distance.

The Mini Planer can be reeled in and removed easily or you can allow it to be tripped so it will slide down to a set stop ahead of the lure depending on which set up you choose. Do **NOT** let the board slide down all of the way to the lure!

## OR34



0 23072 80834 3

OR34 Contains:

- 1 Yellow Mini Planer Board
- 1 OR10 Yellow Release
- 1 OR16 Red Clip
- 1 Snap Swivel
- 1 Black Bracket
- 1 Split Ring
- 1 Nylon Nut
- 1 6/32 x 1/2" Screw

