

OR20

"YOUR LEADER IN TROLLING TECHNOLOGY"

SNAP WEIGHTS

OR20

IN LINE WEIGHTS

PRO WEIGHT SYSTEM



IT'S A **SNAP...** TO GET TO THE FISH!

SYSTEM CONTAINS:

- 4 OR16 Clips
- 4 Split Rings
- 2 1/2 oz.
- 2 3/4 oz.
- 2 1 oz.
- 2 1 1/2 oz.
- 2 2 oz.
- 2 3 oz.

Guppy Weights & Instructions



IN LINE WEIGHT
(Snap swivels not included)



SNAP WEIGHT

www.offshoretackle.com

WARNING: This product contains less than 1% lead, a chemical known to cause cancer, birth defects, and other reproductive harm. Wash your hands after handling this product.



OR20 PRO WEIGHT SYSTEM

IN LINE WEIGHT RIGGING INSTRUCTIONS

LINE TO LURE

LINE TO ROD

SNAP SWIVELS
(not included)

THE IN LINE METHOD

Attach the Guppy Weight as shown on the left.

Once you locate fish, use a Guppy Weight heavy enough to place your rig or bait about a foot or so above the fish you see on sonar. For multiple lines, let out a different distance or use a different weight to let the fish determine the proper combination. Planer boards work very well with in line weights when fish are shallow. When fish are near the surface, the line behind the planer board can be very short. Eight to ten feet is often enough. Once you find the right combination, use it on the rest of your lines.




www.offshoretackle.com



THE 50/50 METHOD

Walleye, steelhead, trout or salmon suspended within 20' of the surface are prime targets for the 50/50 rigging method.




OR20 PRO WEIGHT SYSTEM

SNAP WEIGHT RIGGING INSTRUCTIONS

Set your favorite spoon, spinner or shallow diving crankbait 50-feet behind the boat. Pinch an OR16 Snap Weight Clip onto the line and let out an additional 50-feet of monofilament. This lure and snap weight combination can be fished as a flat line or rigged on an Off Shore Tackle Side Planer or Riviera catamaran style dual (DPB) or triple (TPB) planer board.

When using the 50/50 rigging method, it's best to start fishing with several different weights until the fish communicate which weight and depth range are most productive.



Begin fishing each day with a lure spread that incorporates a variety of snap weight sizes. Staggering lures at different depths is the fastest way to pattern suspended fish. Once a pattern has been determined, switch all lines over to duplicate the productive weight and distance combination.

www.offshoretackle.com